

# Lift-A-Lid and bins



## A hands-free wheelie bin lid lifter

For use in food, medical and industrial operations the Lift-A-Lid bin is the hygienic way to dispose of waste without getting your hands dirty touching the bin.

Simply use the foot pedal to open and close a lidded wheelie bin. Designed and fitted right here in Australia from stainless steel the Lift-A-Lid is perfectly suited for fast paced environments where waste needs to be handled quickly and efficiently.

We also offer the Lift-A-Lid unassembled so you can purchase in bulk and save in shipping and handling charges.

- The bin can be partially opened (and held in place with your foot) for quick use.
- Fully opened for times when large waste needs to be emptied and closed again with a quick press of the pedal.



## Features and benefits

- Australian designed.
- Full stainless steel.
- Can be purchased fully assembled or unassembled.
- Hygienic hands-free operation.
- Can be operated from the front or side.
- Prevents cross contamination from bin to food transfer.
- Costs saving can be achieved by a reduction on handwashing, glove use and hand sanitiser.
- A Lift-A-Lid bin can be emptied by a Liftmaster bin lifter into a bulk bin.
- Can be picked up and emptied by a waste bin truck in the usual weekly/daily collection.
- Compatible with 80, 120 and 240 litre wheel bins.
- Designed to be used only on Sulo and Schaefer bins.

## Typical applications

- Commercial kitchens and food preparation areas.
- Washrooms and bathrooms.
- Medical and healthcare facilities.
- Industrial and construction.
- Any commercial or residential site where emptying waste safely is required.

## Lift-A-Lid kit

The kit consists of:

- A foot pedal frame and vertical bars.
- Hinges.
- Nuts and bolts.



## Order codes

Lift-A-Lid kit options	Bin size	Order code
Kit sold separately. For fitting to your existing wheelie bin.	80 litres	SPLIFTALID80
	120 litres	SPLIFTALID120
	240 litres	SPLIFTALID240
Unassembled kit with wheelie bin. Ideal for buying in bulk.	80 litres	SPLIFTALID80UN
	120 litres	SPLIFTALID120UN
	240 litres	SPLIFTALID240UN
Pre-assembled kit fitted to a wheelie bin.	80 litres	SPLIFTALID80AS
	120 litres	SPLIFTALID120AS
	240 litres	SPLIFTALID240AS

Wheelie bin options	Bin size	Order code
80 litre wheelie bin. Dimensions (H x D x W): 825 x 496 x 440 mm	80 litre	80LTBIN
120 litre wheelie bin. Dimensions (H x D x W): 925 x 555 x 480 mm	120 litre	120LTBIN
240 litre wheelie bin. Dimensions (H x D x W): 1060 x 730 x 550 mm	240 litre	240LTBIN
360 litre wheelie bin*. Dimensions (H x D x W): 1116 x 904 x 669 mm	360 litre	360LTBIN

Spare parts	Order code
Wheelie bin wheels (For more info, see page 60).	RPL200(DTR)

\* The 360LTBIN is a special order. We do not stock this item.



## Easy installation steps

If you purchase the kit unassembled, please follow our easy installation steps for fitting to your existing wheelie bin.

### Tools required for assembly:

- Flat blade screwdriver.
- 5 mm Allen key.
- Shifter.



Watch our instructional video for easy installation.

Take a closer look.  
Scan the QR code.



- 1** Simply remove the wheels from the bin, using a screwdriver.



- 2** Insert the wheel's axle into the foot pedal frame (ensuring the frame is the right way up.)



- 3** Remove the hinge pins from the lid.



- 4** Align the Lift-A-Lid hinges, then reinsert the lid hinge pins.



- 5** Attach the foot pedal bars to the lid hinges using the bolts.



- 6** Tighten using your shifter.



- 7** Then at the base of the bin, attach the foot pedal frame to the vertical bars using the nuts and bolts provided.



- 8** Tighten using your Allen key and shifter. Your bin is now ready to use.

